


Browse for a Show

- INFO** Press twice to display QuickInfo™
- ◀▶** Browse by times (Hold to speed scroll)
- ▲▼** Browse by channels (Hold to speed scroll)

- GUIDE** Display the Guide
- ◀▶** Browse by times (Hold to speed scroll)
- ▲▼** Browse by channels
- 1 2 3** Enter a channel number
- Page** **+** **-** Scrolls channels a page at a time (Hold to speed scroll)




Title Search and Record

- GUIDE** Display the Guide
- C** Display Search Options
- ▲▼** Highlight 'Titles'
- OK** Select 'Titles'
- ◀▶** Highlight a letter Continue typing until titles appear in the Title List
- OK** Select a letter
- ▶** Press until Title List is active OR
- ▶▶** Jump to the Title List (Note: Titles of Current shows are preceded by a dot)

- ▲▼** Highlight a folder
- OK** Expand a folder
- ▲▼** Highlight a title
- OK** Display Title Options
- ▲▼** Highlight an option
- OK** Select an option



Your Remote Control



Quick Tips Guide




Digital Video Recorder Software



Control Live TV or Recorded Shows

- Pause
- Play
- Press twice for Slow Motion
- Three speeds of Rewind
- Three speeds of Fast Forward
- 10 second Instant Replay
- Jump to the Live broadcast



Record Live TV

- Display Recording Options
- Highlight a Recording Option
- Start recording



Schedule a Recording

- Display the Program Guide
- Select a channel
- Select a future time
- Display Recording Options
- Highlight a Recording Option
- Schedule the recording



Keyword Search and Record

- Display the Guide
- Display the Search Menu
- Highlight 'Keywords'
- Select 'Keywords'
- Highlight a letter
- Select a letter
- Press until Title List is active
- Highlight a Keyword Folder
- Display Keyword Options
- Highlight an Option
- Display Recording Options
- Accept the Options



Search for Actors, Directors, Bands, or Characters. A Keyword Series Recording will continue to search for and save matches.

Play, Stop, and Resume Saved Shows

- Display the Saved Shows List
- Highlight a show
- Display Saved Shows Options
- Play the show





- Stop playback & display Options
- Stop and Save



- Display the Saved Shows List
- Highlight a show to resume
- Display Saved Show Options
- Resume Playback

Keep a Saved Show Longer

- Display the Saved Shows List
- Highlight a show
- Display Saved Show Options
- Either**
- Highlight 'Save until manually erased'
- Save the change and continue
- Or**
- Highlight 'Keep Longer ...'
- Display the Priority List
- Move up the list to keep longer
- Save the changes and continue



Manage Scheduled Recordings

- Display Saved Shows
- Display Scheduled Recordings
- Highlight a show
- Display Show Options
- Display Recording Options
- Select an option
- Modify an option
- Accept the changes and continue



Use the Series Manager

- Display Saved Shows
- Display Series Manager
- Highlight a series



Priority Options

- Display Series Options
- Highlight 'Series Recording Priority'
- Display the Priority List
- Make "More Important"
- Make "Less Important"
- Save changes and continue



Recording Options

- Display Series Options
- Display Series Recording Options
- Select an option
- Modify an Option
- Accept the changes and continue



Repeat Options

- Display the Series Options
- Highlight 'Series Repeat Options'
- Display Series Repeat Options
- Highlight an option
- Select any combination of days
- Accept the changes and continue



Cancel a Series Recording

- Display Series Options
- Highlight 'Cancel Series Recording'
- Display Cancel Series confirmation
- Accept the changes and continue

